

JM 1065 Victoria's Farmhouse

Printable Checklist

- Identify and label all of the parts
- Pre-Assemble: Front Steps, Chimney, Bay Wall Sets, Foundation, and the Top Floor/
Gable Floor
- Paint everything one coat
- Option: Faux-wood floor finish on the floors
- Sand everything until the paint is smooth, transparent, and some of the wood is showing through
- Second-coat the Walls, and the porch sections of the Floors
- Option: Add an Electrification Slot to the Base Floor
- Build the housebody up to the Attic Endwalls and Gable Triangle
- Optional: Start the wiring
- Mark, paint, and attach the Roofs (but not the Rear Roof)
- Optional: Attic wiring
- Install the Dividers (but not the Blind Dividers)
- Optional: Finish the wiring
- Assemble and finish painting everything else
- Finish the Attic - attach the Rear Roof
- Finish the outside
- Finish the inside