


#5 Ceiling and Sconce

This is not the limit of what can be wired. A tap at the top of the wall could wire the Porch Ceiling,  or outlets can be wired through the wall to the Base Loop on the inside for outlets on the Porch or to the Sconce Loop for sconces on the Balcony... more wiring can go to the front of the Gable or into the Front Bay. Imagine anywhere you might want a fixture or seasonal decorations in the future and provide for that option now.

Note: Coach Lights beside the Front Door should be wired into the same eyelets that join the Sconce Loops to the Base Loop where it goes around the door

