

Sconce runs and front-to-back ceiling runs are optional, depending on your wiring plan. Notice that connections avoid folded corners (a "T" however would work where a connection at a corner is necessary).

