

Lay the Base Loops and the Sconce Loops. Each Loop is in one piece, no connections. Use folded (pleated) corners around the Door or Window. Lay the Ceiling runs.



Folded corners around the Door.
There are no eyelets in folded corners!

Install the Jack in the foundation.



Attach the Jack to the House Wiring following the wiring kit's instructions.



... wired to one or both flaps in the cellar for houses with E-Slots



... wired thru drilled holes in the Base Floor

