

Sconce and Ceiling Runs

The run up the stairwell must be closer to the back (closer to you in this view) to avoid the doorway in the first floor.

The Tower vertical run will have a folded corner at the top to aim along the top of the Tower Walls; it will get an outlet for a ceiling light. Energizing the Tower Ceiling/Roof with a plug allows the Tower Ceiling/Roof to be removed for future access.

