

Sconce and Ceiling Runs

Ceiling runs are front-to-back runs, often in the center of the rooms, but should be located to accommodate your lighting plan.

Sconce Runs and Ceiling Runs can be more continuous with folded corners around the windows (see the dotted lines in the attic). In this house, some of the spaces are too tight to effectively fold around the windows (see the attic tower room)... you decide.

Sconce runs in the Attic require Pocket Re-Directs 

Sconce Runs continue into Additions through the doors

