



### Step 3

Up-and-over loops (red) in the rear rooms. These runs must be positioned to avoid the door cutouts into the additions, and to avoid the stair hole in the Top Floor

Up-and-over loops (red) in the front rooms. These runs must be at least  $\frac{3}{4}$ " behind the edges of the Bay Walls

Up-and-over loop (red) in the Attic. This run is ideal if it is in the center of the back hall (with the Attic Dividers temporarily in place), but you may have other constraints that will control its position