



Step4

Base Runs (red) $\frac{3}{4}$ " above the floors (use the layout stick from the wiring set). The ends of the runs must at least cover the whole width of the Up-and-Over Loops in order to be able to connect to them later.

The middle Base Runs are in one piece and have folded corners around the Front door cutouts. They go through the Divider doors.

*If you have Additions, the runs go thru the doors to electrify the Addition following the same pattern as the main house.

If desired, lay scribe runs $5\frac{1}{2}$ " above the floors.

