



### Step5

Make a pocket so the tapewire can go around a non-square corner without being re-directed downward. You do this by making a square corner for the tapewire inside a pocket at the corner, and laying a wrinkle of tapewire into the pocket, then spackling to leave a smooth corner for wallpaper. This can be done with a knife, an Oscillating Multitool, or (my favorite) a rotary tool and burr like a Dremel (see "Tools and Techniques").

