



Step 6

Base Runs (red)  $\frac{3}{4}$ " above the floors in both of the Middle Dividers. The runs go through the door and connect to an Up-and-Over run on each side. The ends of the runs must at least cover the whole width of the Up-and-Over Loops in order to be able to connect to them later.

If desired, lay scone runs  $5\frac{1}{2}$ " above the floors.

Lay a Front-to-Back Ceiling Run in each room, centered side-to-side. Consider your plan for ceiling lights over the stairs and move or add to this plan accordingly.